

Software:
Do not probe low
voltage during charging.

PA8 and P10 are swapped in the Discovery board documentation!!!

